

VERY IMPORTANT

PLEASE NOTE that the Murphy bed
**MUST BE SECURELY ATTACHED TO THE WALL
AT THE STUDS**

before you attempt to attach the piston/gas spring(s)

INSTALLING A COMPRESSED PISTON:

1. BEFORE installing the piston, use a utility knife to scrape some of the wood underneath the LOWER BALL STUD PLATE so that the piston head and metal compression band have room to snap on the lower ball stud without binding up.
2. Snap the skinny end of the piston onto the lower silver ball stud.
3. Raise the bed face panel approximately 45 degrees and snap the fat end of the piston onto the upper silver ball stud.
4. Push the bed face panel down toward the floor and remove the steel band from the piston. ↓
5. Repeat on the other side of the bed face panel.

To view a video of this installation process, go to this page:
<http://bit.ly/installcompressedpiston>