

Alpha Murphy Bed

(Outset Lights)



It's like having your own shop!

Assembly Instructions Face Assembled

Questions call 501.753.9699

Designed to exceed International ISO 9002
Standards for Residential Specifications
Revised 4/28/25

Table Of Contents

[Unpacking Your Bed](#)

[Videos](#)

[Assemble the Bed Cabinet](#)

[Light Step 1](#)

[Attach Bed Cabinet Securely to Wall](#)

[Lights Part 2](#)

[Install the Bed Face Panel Unit](#)

[Install Legs](#)

[Mounting the Face](#)

[Follow up to Initial Assembly](#)

[Additional Options](#)

[Bookcase Option](#)

[Desk Option](#)

[Desk Step D-1 | Attach the Desk Riser to the Desktop.](#)

[Desk Step D-2 | Attach the Desk Mechanism to Desk](#)

[Desk Step D-3 | Place Desk Hinge into Hinge Clip](#)

[Desk Step D-4 | Reattach Base](#)

[Desk Step D-5 | Check Operation](#)

[Frequently Asked Questions](#)

Unpacking Your Bed

Remove all boxing, foam, and shrink wrap and make sure all components are there. Each customer piece will vary but in general you should have:

Do not throw away packaging until you are complete (smaller items could be lost in packaging)

Parts Provided	Tool Needed
<ul style="list-style-type: none"><input type="checkbox"/> 2- Verticals<input type="checkbox"/> 1-Top panel/Header<input type="checkbox"/> 1-Headboard<input type="checkbox"/> 1-Center Section<ul style="list-style-type: none"><input type="checkbox"/> Unassembled face may be 4 individual panels and the metal frame boxed<input type="checkbox"/> Package of screws<input type="checkbox"/> Extras may include:<ul style="list-style-type: none"><input type="checkbox"/> Crown or base molding<input type="checkbox"/> Bookcases (adjustable shelves will be packed separately)<input type="checkbox"/> Desk	<ul style="list-style-type: none"><input type="checkbox"/> Power drill<ul style="list-style-type: none"><input type="checkbox"/> 3/16" drill bit<input type="checkbox"/> Phillips bit<input type="checkbox"/> 1/2" wrench<input type="checkbox"/> 7/16" wrench or nut driver<input type="checkbox"/> Hammer<input type="checkbox"/> Flathead Screwdriver<input type="checkbox"/> Stud Finder<input type="checkbox"/> Tape Measure<input type="checkbox"/> 1/2" socket <p>Additional tools if the Face isn't already assembled:</p> <ul style="list-style-type: none"><input type="checkbox"/> 5/16" socket, wrench or nut driver<input type="checkbox"/> #2 Square drive for your drill

Videos

To make the assembly easier, we created a couple of video playlists. As with these instructions, the videos are generic and not all may apply to your specific set-up.

[Play all Videos | Entire Playlist](#)

Individual Videos

[Parts](#)

[Tools Required](#)

[Adding Springs](#)

[Mounting the Lift Mechanism](#)

[The Cabinet Part 1](#)

[Lights](#)

[Cabinet part 2](#)

[Attaching to wall](#)

[Locking Spring](#)

[Frame Bolts and Straps](#)

[Legs](#)

[Mounting the Face](#)

[Finishing Up](#)

Assemble the Bed Cabinet

Step 1: Familiarize yourself with these instructions.

Step 2: Clear out an area in your room.

Video: [The Cabinet Part 1](#)

- If possible, the Bed Cabinet should be assembled in the room where it will be used.
- Be sure Lift Mechanisms are securely installed.

Headboard and Top Panel Installation

On a soft surface like a blanket lay out the verticals.

3-1. Insert the headboard dowels into the ends of the headboard (two on each side).

No need to measure, The dowels will align

the headboard to where it needs to be. With the pocket screw holes facing toward the back, insert the headboard dowels into the side of the verticals.

3-2. Lay the verticals on the floor with the mechanism facing up and the head of the bed toward the wall.

3-3. Place the dowels in the end of the headboard into the dowel holes in the vertical making sure the headboard screw pockets are facing toward the back and the finished edge of the headboard is facing what would be up (when lying on the floor, finished edge will be away from the wall)

3-4. Secure headboard to the verticals with 1 ½" screws (4 each side).


3-5. Carefully rotate the headboard and the one vertical so that the other end of the headboard/dowels can be inserted into the second vertical. The unit should now be face down.

3-6. Secure this other end of the headboard to the verticals with 1 ½" screws (4 each side).

Top Panel

3-7. With the bed still face down on the floor attach the top panel. Top panel should be flush with the top of the verticals and the front.

3-8. Secure each side with five 1-½" screws.



Light Step 1

(If you do not have lights skip this step)

Video: [Lights](#)


IMPORTANT: If you have lights, you will want to make sure your wiring and control box are in place before mounting to the wall. These steps will be performed while the cabinet is still face down.

L-1 The control box and touch plate should already be connected to the back of the headboard.

NOTE: If you have Outset lights there will be a second single wire connected to the back of the Touch Plate. This wire will be routed to the second Touch Plate Location (Typically the left side). This second location will be on the left side toward the back of the left bookcases. If no bookcases, the location will be on the Left/back of the Murphy bed cabinet.

L-2. Connect the standard female plug end coming out of the control box into the extension cord running up the vertical.

Figure L-1b (Outset Lights)



BACK TO REGULAR INSTRUCTIONS

Video: [Cabinet part 2](#)

Stand the unit up and into its approximate place in the room. Check that the cutout made to clear your base molding is sufficient. If not make the height it needs to be. Lay the unit back down on the face, and adjust the cutout.


Bottom Rear Base and Bottom Kick

Bottom Rear Base and Bottom Kick will be the same width (4") Some drawings may show them different sizes.

If you have the added base molding this base molding may be attached to the Front Bottom Kick as in this example.

3-9. Attach the Bottom Rear Base. Both the Bottom Rear Base and Bottom Kick will be the same height. You may want to use the better one for the front Bottom Kick. With the brackets facing toward the front, bring the Bottom Rear Base in so that it clears any cutouts that were made for the base molding

3-11. Attach the Bottom Kick by setting it back 1" from the front of the Side Panels. These brackets will face the wall/inside. Secure with $\frac{3}{4}$ " screws.



Special application: If you have added base molding, the Bottom Kick may be attached to that base molding and may not have the 1" set back. Also in some cases the Bottom Kick will be replaced by added base molding.

Attach Bed Cabinet Securely to Wall

Video: [Attaching to wall](#)

4-1: Find Studs


Prior to placing the cabinet against the wall, locate 3-4 studs on queen size (4-5 on King) or other wall frame members at the level of the Top Panel (top of bed). Alert: The cabinet must be secured to studs or other wall structural members or injury and damage could occur. If the wall is not a wood stud wall, use metal stud screws, toggle bolts or concrete expansion bolts if necessary.

Tip: for help finding studs there are several websites of video available online, just do a google search. One example: <https://www.lowes.com/n/how-to/how-to-find-studs-in-walls>

4-2: Attach to wall

Now that the cabinet is square and plumb, **pre-drill a hole in that backboard of the Top Panel/header at the stud location using a 3/16" drill bit. Only pre-drill that back board and not the entire depth into the stud. Fasten cabinet to wall using 3" screws. Repeat this for other stud locations.**

If the wall is **CONCRETE, MORTAR OR BRICK** Construction, use masonry screws: Drill three pilot holes through the rear rail of the bed header into the wall for a twin or full and four for a queen size bed. Using a 5/32" concrete drill bit, drill through the pilot holes into the wall 2" deep. Anchor the bed by screwing 3/16 x 2 1/4" masonry screw through the rear rail of the bed header into the wall.



IMPORTANT:

After the cabinet is securely fastened to the wall, pull on the top of the cabinet. If any movement away from the wall is detected, repeat the previous steps.

Lights Part 2

L-3 If there are bookcases, bring them near the bed section. Connect the wire leading from the bookcase touch plate to the wire from the headboard touch plate.


L-4. Plug the top side of the extension cord that is running up the verticals into the lights. If you have bookcases, start with that far left bookcase.

L-5 Connect the second wire for the bookcase to first light in the bed section. All lights should be connected in a series.

L-5 . Back down under the headboard, plug the power end of the control box into your wall outlet.

L-6 Test the lights. With the outset lights the lights should come on when any of the touch plates are touched.

Figure L-1b (Outset Lights)



Install the Bed Face Panel Unit


Lock the arm into place

Videos: [Locking Spring](#) and [Frame Bolts and Straps](#)

Caution: If possible have a helper assist in the setting of the mechanism and loading of the bed face panel. DO NOT reach behind the tension arm when you are doing the setting procedure. To avoid reaching behind the Tension Arm, use a pencil or screw driver to move the Arm Lock into place.


Holding one foot against the bottom front edge of the side panel and using the “Tension Arm Lever Tool”, pull the tension arm out until you can set the arm lock to the hex nut at the hole A (see drawing 13.). This is the hex nut at the top front corner of the mechanism.

Tip: If you set the “Arm Lock” on top of the bolt before you pull the Tension Arm back it will fall into place. Do not put your fingers back there while pulling it back!



5-1: Check the location of the bolts on the frame. You should have an allen head screw in hole #1, and a loose Hex Head bolt in hole #3. Hole #2 should be empty.




NOTE: Holes shown in the video may be slightly different.



Install Legs

Video: [Legs](#)

7-1 Install legs with the washers on the inside of the Rails and the Nylon washer on the outside. Tighten nut to have a small amount of friction when leg assembly is rotated from the up to the down position.




7-2 Install leg connector rod between legs and secure with 1/4"x1 1/4" (M4x32mm) Hex head bolts and star washers. Be sure they are securely tightened so as not to become loose.

Mounting the Face


Video: [Mounting the Face](#)

NOTE: Two people are needed for this step.

6-1. Lift the unit vertically to a height where the bolts in holes #3 are several inches above the top of the Tension Arms. Gently fit the unit between the arms, tilt it back approximately 10 degrees so that the head end of the unit clears the Bottom Kick, then lower it so that the #3 bolts slide into the slots at the end of the Arms. **Be sure the Allen Head cap seats at the bottom of the slots on the tension arm.** Slowly tilt the panel unit back just enough to allow the #1 Allen Head Cap bolts to be fully seated in the notches at the bottom of the Mechanism. As in Drawings 14, 15, and 16.




Drawing 14.



Drawing 15.

6-2 Continue to tilt the Bed Panel Unit outward to an angle of about 45 degrees, during which action you will hear a click as the Arm Locks disengage. With your assistant holding the bed at roughly this angle, install the #2 bolts and Nuts. Still holding the panel unit at this angle securely tighten the #2 and #3 nuts.

6-3 When all bolts are securely tightened, you may tilt the panel outward to approximately 45 degrees to release the arm locks. You will hear a click as they disengage.



Caution:

Hold the Face Panel securely, Do Not let it slam shut. Balance is not achieved until the mattress is loaded in the bed otherwise it will not stay down. Also make sure the legs are folded around and above the mattress space.

Holding the upper edge of the Bed Panel Unit, gently let the bed close. If all is well, you should have even clearance between the side edges of the panel unit and the insides of the Side Panels.

If the Cabinet is not square and the Bed Panel Unit binds try the following adjustments.

- Nudge the Bed Cabinet along the floor, pushing from the base of the Side Panel
- Shim (or reshim) the bottom of the Side Panels for floors that may be out of square.

Complete Bed Assembly

Follow up to Initial Assembly

Video: [Finishing Up](#)

Check that the Bed Cabinet is level and square so the Bed Face has equal clearance of the Cabinet on both sides, top to bottom. If the Cabinet is leaning to one side, nudge it at the floor level. If the top is uneven, place shims under the Side Panels. If bed is too heavy to operate easily or slams shut, remove the Bed Face Panel and add or subtract springs. At this time, you may decide to use one more or less spring(s) on the left or right side Lift Mechanism.



7-1 Add Cover Plates

You should have a left and right cover plate and two 1-1/2" wood screws. The cover plates have tabs on them. Slide those tabs into the slot in the top of the mechanism.

Slip the Mechanism Cover over the Mechanism so that the tabs on the cover fit into the notches. Line up the hole with the barrel support and anchor in place using the 1-1/2" screw provided Repeat on the other Mechanism.

7-2 Load and strap the mattress into place. Two people are needed.

7-3 Add any accessories like crown or bookcases.



Additional Options

Bookcase Option

Most bookcases are not designed to be flush with the back wall. The bookcase will mount to the bed at the top using 1 ¼" screws. You can also put one inside the lower section by pulling out a drawer. We may not have pre-drilled for these holes so you can place them anywhere.

All Bookcases are Custom, but a good rule of thumb is:

- 17 7/8" D Bookcases | Flush with LED Outset Lights or backset approximately 1" if there is Crown
- 13 7/8" D Bookcase | Flush with the Bed Verticals or backset approximately 1" if there is Crown.
- 11 7/8" Bookcases | Backset 2 ½" from Murphy Bed Face

Desk Option

Video: [Installing the Stay Level Desk](#)

Video: Installing the Stay-Level Desk

Note: On some applications we have put the screws back in on the face (right above the Desk Bracket) and also at the bottom, into the Side panels. If this is the case remove those screws and use them to assemble the desk. If not you should find them labeled in your hardware pack.

Desk Step D-1 | Attach the Desk Riser to the Desktop.


If they are not already inserted, insert the hardwood dowels into the bottom of the Desk Riser. The Desk Riser will attach to the Desktop by inserting the dowel side into the dowel holes on the Desktop. Keep in mind there is usually a front and a back to the Desk Riser. Make sure the good side is facing forward.



Note: the holes cut in the Desktop are elongated and allow left to right movement. Make sure the edges of the Desk Riser and Desktop are even and insert the 1 ½" screws.

Desk Step D-2 | Attach the Desk Mechanism to Desk

The Desk Mechanism has holes in the Desk Upper Bracket that forms an "L". Attach the desk to the mechanism using 20 - 5/8" pan head screws.




Desk Step D-3 | Place Desk Hinge into Hinge Clip

NOTE: Two people are needed for this step

With the Desk rotated 90° up, place the loose end of the hinge into the Hinge Clip and secure with $\frac{5}{8}$ " flat-head screws.

NOTE: Some heavier desks may use a combination of machine screws and wood screws. The center hinge will be secured with two machine screws (center hole may be skipped completely). Each outer hinge will use one machine screw in the center hole and wood screws in the outer holes.




Desk Step D-4 | Reattach Base

Rotate the desk back down and re-insert the $\frac{5}{8}$ " pan-head screws that were removed from Step D-1.

Desk Step D-5 | Check Operation

Check the desk for level and open and close the bed to make sure the bed is operating properly.

Notes:



Frequently Asked Questions

There is a larger gap between the face and sides on one side:

The cabinet is slightly out of square. The bottom needs to be moved one direction or another. See video clip on [how to adjust the gaps](#).

The bed will not stay closed and opens slightly:

The bed is designed to have some weight behind the pivot point, provided by the mattress to pull it closed. If the mattress has not been added to the frame, add the mattress and that should take care of the problem.

I am having trouble finding a stud in my wall:

Murphy beds must be securely attached to the wall before use. Failing to do so could cause serious injury. Use a stud finder to mark the edges of the stud, but sometimes those may give mixed results.

Use an existing room outlet as a reference. Normally your home's outlet boxes are attached to the wall studs and therefore one should be on the left or right of that outlet box.

An alternative method to a stud finder is a high strength magnet. This works by locating the screws holding the drywall to the studs. Once you locate one stud, others can be easily located. Most studs are 16" apart, therefore check at 16" interval for the next one.

The face will not stay down when open:

First make sure there is a mattress in the frame. The spring load is tested for an average weight mattress and should cover a fairly wide range of mattress weights. If the mattress is lighter than expected the foot may slightly lift. You may want to remove springs. Use this document to help with [adding or removing springs](#).

A temporary method is adding weight under the mattress. A flat board added toward the foot of the bed and secured to the back side of the face works well until you can follow the procedures for [adding or removing springs](#).

The face is heavy to lift:

The spring load is tested for an average weight mattress and should cover a fairly wide range of mattress weights. It is also designed to have a little more weight on the ground when all the way open, so some weight is normal. If you have a heavier mattress, this may require an additional spring to be added to each side. Use this document to help with [adding or removing springs](#).